

DEWALT®

D21101

lish	English
中文	简体中文





В

ROTARY DRILL D21101

Congratulations!

You have chosen a DeWALT Power Tool. Years of experience, thorough product development and innovation make DeWALT one of the most reliable partners for professional Power Tool users.

Technical data

	D21101
V	220
W	650
min⁻¹	0 - 850
mm	13/38
UNF	1/2" x 20
mm	43
mm	13
kg	1.8
	mm UNF mm mm

Fuses:	
220-240 V tools	10 Amperes, mains

The following symbols are used throughout this manual:



Denotes risk of personal injury, loss of life or damage to the tool in case of nonobservance of the instructions in this manual.



Denotes risk of electric shock.

General safety rules

Warning! Read all instructions. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury. The term "power tool" in all of the warnings listed below refers to your mains operated (corded) power tool or battery operated (cordless) power tool. SAVE THESE INSTRUCTIONS.

- 1 Work area
- a Keep work area clean and well lit. Cluttered and dark areas invite accidents.
- b Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- c Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

2 Electrical safety

- a Power tool plugs must match the outlet.

 Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- b Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- c Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- d Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- e When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.

3 Personal safety

a Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.

- b Use safety equipment. Always wear eye protection. Safety equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- c Avoid accidental starting. Ensure the switch is in the off position before plugging in. Carrying power tools with your finger on the switch or plugging in power tools that have the switch on invites accidents.
- d Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- e Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- f Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- g If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of these devices can reduce dust related hazards.
- 4 Power tool use and care
- a Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- b Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- c Disconnect the plug from the power source before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.

Check for misalignment and seizure of moving parts, breakage of parts and any other conditions that may affect its operation.

Have damaged guards or other defective parts repaired or replaced as instructed. Do not use the tool if the switch is defective. Have the switch replaced by an authorized D

5 Have your tool repaired by an authorized D∈WALT repair agent

This Power Tool is in accordance with the relevant safety regulations. To avoid danger, electric appliances must only be repaired by qualified technicians.

Package contents

The package contains:

- 1 Rotary drill
- 1 Chuck key
- 1 Instruction manual
- 1 Auxiliary handle
- 1 Warranty card
- 1 Service address card
- Check for damage to the tool, parts or accessories which may have occurred during transport.
- Take the time to thoroughly read and understand this manual prior to operation.

Description (fig. A)

- 1 Variable speed switch
- 2 Lock-on button
- 3 Forward/reverse slider
- 4 Ventilation slots
- 5 Keyed chuck
- 6 Sleeve
- 7 Chuck kev
- 8 Auxiliary handle

Electrical safety

The electric motor has been designed for one voltage only. Always check that the power supply corresponds to the voltage on the rating plate.



Your DEWALT tool is double insulated in accordance with IEC 60745; therefore no earth wire is required.

Using an extension cable

If an extension cable is required, use an approved extension cable suitable for the power input of this tool (see technical data). The minimum conductor size is 1.5 mm². When using a cable reel, always unwind the cable completely.

Also refer to the table below.

Conducto	Cabl	e ratir	ng (Am	peres)		
0.75		6					
1.00		10					
1.50		15					
2.50		20					
4.00		25					
Cable length (m)							
		7.5	15	25	30	45	60
Voltage	Amperes	Cable rating (Amperes)					
220-240	0 - 2.0	6	6	6	6	6	6
	2.1 - 3.4	6	6	6	6	6	6
	3.5 - 5.0	6	6	6	6	10	15
	5.1 - 7.0	10	10	10	10	15	15
	7.1 - 12.0	15	15	15	15	20	20
	12.1 - 20.0	20	20	20	20	25	-

Assembly and adjustment



Prior to assembly and adjustment always unplug the tool.

The tool can be used in rotary drilling for steel, wood and plastics.



Inserting and removing a bit (fig. A)

Keyed chuck

- Open the chuck by turning the sleeve (6) counterclockwise and insert the bit shank.
- Put the chuck key (7) into each hole in the side of the chuck and turn clockwise until tight.
- To remove the bit, proceed in reverse order.

Forward/reverse slider (fig. A)

 To select forward or reverse rotation, use the forward/reverse-switch (3) (see arrow on tool).



Always wait until the motor has come to a complete standstill before changing the direction of rotation.

Chuck removal (fig. B)

- Open the chuck jaws as far as possible.
- Insert a screwdriver into the chuck and remove the chuck retaining screw (9) by turning clockwise.
- Tighten an Allen key into the chuck and strike it with a hammer as shown.

Instructions for use



- Always observe the safety instructions and applicable regulations.
- Be aware of the location of pipework and wiring.
- Apply only a gentle pressure to the tool.
 Excessive force does not speed up drilling but decreases tool performance and may shorten tool life.
- Use auxiliary handles supplied with the tool. Loss of control can cause personal injury.

Prior to operation:

- Insert the appropriate bit.
- Mark the spot where the hole is to be drilled.

Switching on and off (fig. A)

- To run the tool, press the variable speed switch (1).
 The pressure exerted on the variable speed switch determines the tool speed.
- If necessary, press the lock-on button (2) for continuous operation and release the switch.
 The lock-on button works only in full speed, forward rotation.
- To stop the tool, release the switch.
- To stop the tool in continuous operation, press the switch briefly and release it. Always switch off the tool when work is finished and before unplugging.

Screwdriving

Select forward or reverse rotation.

Consult your dealer for further information on the appropriate accessories.

Maintenance

Your DEWALT Power Tool has been designed to operate over a long period of time with a minimum of maintenance. Continuous satisfactory operation depends upon proper tool care and regular cleaning.



Lubrication

Your power tool requires no additional lubrication.



Cleaning

Keep the ventilation slots clear and regularly clean the housing with a soft cloth.



Unwanted tools and the environment

Take your tool to an authorized DEWALT repair agent where it will be disposed of in an environmentally safe way.

D21101电钻

祝贺您!

您已选择了得伟电动工具。多年的行业经验、全面的产品开发和创新能力,使得伟成为了电动工具使用者最可信赖的伙伴之一。

技术数据

		D21101
电压	V	220
输入功率 -A9	W	650
空载转速	min ⁻¹	0 - 850
钢材 / 木材		
最大钻孔直径	mm	13/38
夹头螺纹口尺寸	UNF	1/2" x 20
轴环直径 [*]	mm	43
夹头最大尺寸(直径)	mm	13
重量	kg	1.8

保险丝:		
220-240	伏特	10安培

本手册中普遍使用下列符号:



表示如违反本手册中的有关指示,将有 造成人身伤害、死亡或者工具损坏的危 险。



表示电击危险。

一般安全规则

警告!请仔细阅读本手册的全部指令。如未能遵守下列任何指令,则可能会导致电击、火灾和/或严重的人身伤害。下文所有警告中的"电动工具"一词指您的电网电源供电(有绳)电动工具、或电池驱动的(无绳)电动工具。

请妥善保管本手册,以备将来参考使用。

1工作场地

- A) 保持工作场地清洁和明亮。混乱和黑暗的场地 会引发事故。
- B) 不要在易爆环境,如有易燃液体、气体或粉尘 的环境下操作电动工具。电动工具产生火花会 点燃粉尘或气体。
- C) 让儿童和旁观者离开后操纵电动工具。分心会 使你放松控制。

2 电器安全

- A) 电动工具插头必须与插座相配,绝不能以任何 方式改装插头。需要接地的电动工具不能使用 任何转换插头。未经改装的插头和相配的插座 将减少触电危险。
- B) 避免人体接触接地表面,如管道、散热片和冰箱。如果你身体接地会增加触电危险。
- C) 不得将电动工具暴露在雨中或潮湿环境中。水 进入电动工具将增加触电危险。
- D) 不得滥用电线,绝不能用电线搬运、拉动电动工具或拔出其插头。让电动工具远离热、油、 锐边或运动部件。受损或缠绕的电线会增加触 电危险。
- E) 当在户外使用电动工具时,使用适合户外使用 的外接电线。适合户外使用的电线将减少触电 危险。

3 人身安全

- A) 保持警觉,当操作电动工具时关注所从事的操作并保持清醒。切勿在有疲倦,药物、酒精或治疗反应下操作电动工具。在操作电动工具期间精力分散会导致严重人身伤害。
- B) 使用安全装置。始终佩戴护目镜。安全装置, 诸如适当条件下的防尘面具、防滑安全鞋、安 全帽、听力防护等装置能减少人身伤害。

- C) 避免突然启动。确保开关在插入插头时处于关 断位置。手指放在已接通电源的开关上或开关 处于接通时插入插头可能会导致危险。
- D) 在电动工具接通之前,拿掉所有调节钥匙或扳 手。遗留的电动工具旋转零件上的扳手或钥匙 会导致人身伤害。
- E) 手不要伸得太长。时刻注意脚下和身体平衡。 这样在意外情况下也能很好地控制电动工具。
- F) 着装适当。不要穿宽松衣或佩带饰品。让你的 头发、衣服和袖子远离运动部件。宽松衣服、 佩饰或长发可能会卷入运动部件。
- G) 如果提供了与排屑装置、集尘设备连接用的装置,则确保他们连接完好且使用得当。使用这些装置可减少碎屑引起的危险。

4 电动工具使用和注意事项

- A) 不要滥用电动工具,根据用途使用适当的电动工具。使用适当的设计额定值的电动工具会使你工作更有效、更安全。
- B) 如果开关不能接通或关断工具电源,则不能使 用该电动工具。不能用开关来控制的电动工具 是危险的且必须进行修理。
- C) 在进行任何调节、更换附件或贮存电动工具之前,必须从电源上拔掉和/或将电池盒取下。 这种防护性措施将减少电动工具突然启动的危险。
- D) 将闲置电动工具贮存在儿童所及范围之外,并 且不要让不熟悉电动工具或对这些说明不了解 的人操作电动工具。电动工具在未经训练的用 户手中是危险的。
- E) 保养电动工具。检查运动件的安装偏差或卡 住、零件破损情况和影响电动工具运行的其他 条件。如有损坏,电动工具必须在使用前修理 好。许多事故由维护不良的电动工具引发。
- F) 保持切削刀具锋利和清洁。保养良好的有锋利 切削刃的刀具不易卡住而且容易控制。

以确保工具的正常工作,且能完成预定的功能。检查运动部件是否有偏移或卡住、部件是否有破损,以及是否存在其它可能对操作造成影响的情况。依照指引,将破损的保护装置或其它故障部件送去维修或进行更换。如果开关出现故障,不要使用该工具。将开关交由得伟授权的维修商更换。

5 将工具交由得伟授权的维修商维修本电动工具符合相关的安全法规。为避免危险, 电器设备必须仅由具备资格的技术人员进行维修。

包装内容

包装内包括:

电钻一台 夹头钥匙一把 辅助手柄一把 使用手册一本 质保卡一份 维修服务联系卡一份

- 检查工具、部件或配件是否有在运输过程中可能 出现的损坏情况。
- 操作前通读并完全了解本手册的指示。

图 A 描述

- 1 电子无级调速开关
- 2 锁定按钮
- 3 正反转开关
- 4 通风口
- 5 钻夹头
- 6 套筒
- 7 夹头钥匙
- 8 辅助手柄

电气安全

电机设计只能使用一种电压。每次使用均应检查电源与铭牌上的电压是否相符。



您的得伟工具已按照 IEC 60745 标准采 用双重绝缘设计,因此无须连接地线。

使用延长电缆

如要使用延长电缆,应当使用经核准的适用于本工 具输入功率的(见技术数据)延长电缆。最小应采用导 体截面积为1.5平方毫米的电缆。使用电缆盘时,应 切记将电缆完全展开。另外可参照下表。

		1 141 1					
导体截面积:	电缆器	预定电 济	f值 (安	培)			
0.75		6					
1.00		10					
1.50		15					
2.50		20					
4.00		25					
		电缆士	长度 (米	:)			
		7.5	15	25	30	45	60
电压 (伏)	电流 (安培)	电缆额定电流值 (安培)					
220-240	0 - 2.0	6	6	6	6	6	6
	2.1 - 3.4	6	6	6	6	6	6
	3.5 - 5.0	6	6	6	6	10	15
	5.1 - 7.0	10	10	10	10	15	15
	7.1 - 12.0	15	15	15	15	20	20
	12.1 - 20.0	20	20	20	20	25	-

装配与调整



装配和调整前,切记将工具电线拔下。

本工具可以用于电钻模式:该模式用于钢材、木材 和塑料。



装卸钻头 (图B)

有匙夹头

- 逆时针方向旋转夹头(6), 并装入钻头柄。
- 将夹头钥匙(7)插入夹头侧面的孔中,并顺时 针旋转直到旋紧。
- 如要取出钻头, 按上述步骤反序操作。

正反转开关 (图A)

要选择正或反旋转,请使用正反转开关(3)(如工具上的箭头所示)。



切记要等到马达完全停止后, 方可改变 旋转方向。

夹头的拆卸 (图B)

- 将夹头按逆时针方向转到最大位置。
- 将螺丝刀伸入夹头,顺时针旋转,取出固定夹 头的螺丝(9)。

使用指引



- 务必遵守安全指引和适用之法规。
- 留意施工场地的管道系统和布线位置。
- 给工具施加适当的压力。过度用力并不 能加快钻孔速度,反而会降低工具的工 作表现,还可能缩短工具的使用寿命。
- 使用随工具提供的辅助手柄。操作失手 会引起人身伤害。

操作前:

- 装入适当的钻头。
- 在要钻孔的位置上做好标记。

打开与关闭开关 (图A)

- 要启动工具,按下调速开关(1)。在调速开关上 施加的压力大小,决定工具运行速度的快慢。
- 要停止工具运行, 松开调速开关即可。
- 如有必要,按下锁定按钮(2),使工具持续工作。
 锁定按钮仅在正转状态下有效。
- 要让连续工作的工具停止运行,快速按下开关并 释放之。切记在工作完成时和拔下插头前关闭工 具。

拧螺丝

• 选择正反转。

请联系您的经销商,征询有关适当配件的进一步信 息。

维护

您的得伟动力工具设计精良,可以长期运作,而只 需极少的维护。要取得连续的令人满意的工作效 果,需要您做合适的保养和定期的清洁。



润滑

您的动力工具不需要额外的润滑。



清洁

保持通风孔的清洁, 并定期用软布清洁工具外 壳。



废弃工具与环境

将您废弃的工具拿到得伟授权的维修点,他们会以 对环境安全的方式处置您废弃的工具。

制造商: 百得(苏州)科技有限公司地址: 苏州工业园区出口加工区