





Dustbuster FLEXI 12 Volt Vacuum Cleaner

Technical data

	PD1200
Voltage	Vdc 12
Weight	kg 1.8

Charger

Input voltage	Vac 230
Approx. charging time	h 16
Weight	kg 0.3

Intended use

Your Black & Decker Dustbuster Flex vacuum cleaner has been designed for dry vacuum cleaning purposes. This appliance is intended for household use only.

Safety instructions

Warning! When using battery-powered appliances, basic safety precautions, including the following, should always be followed to reduce the risk of fire, leaking batteries, personal injury and material damage.

- ◆ Read all of this manual carefully before using the appliance.
- ◆ The intended use is described in this manual. The use of any accessory or attachment or the performance of any operation with this appliance other than those recommended in this instruction manual may present a risk of personal injury.
- ◆ Retain this manual for future reference.

Using your appliance

- ◆ Do not use near water.
- ◆ Do not use the appliance to pick up liquids or any materials that could catch fire.
- ◆ Do not immerse the appliance in water.
- ◆ Never pull the charger lead to disconnect the charger from the socket. Keep the charger lead away from heat, oil and sharp edges.
- ◆ This tool is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

After use

- ◆ Unplug the charger before cleaning the charger or charging base.

- ◆ When not in use, the appliance should be stored in a dry place.
- ◆ Children should not have access to stored appliances.

Inspection and repairs

- ◆ Before use, check the appliance for damaged or defective parts. Check for breakage of parts, damage to switches and any other conditions that may affect its operation.
- ◆ Do not use the appliance if any part is damaged or defective.
- ◆ Have any damaged or defective parts repaired or replaced by an authorized repair agent.
- ◆ Regularly check the charger lead for damage. Replace the charger if the lead is damaged or defective.
- ◆ Never attempt to remove or replace any parts other than those specified in this manual.

Additional safety instructions for batteries and chargers

Battery and charger

- ◆ Never attempt to open for any reason.
- ◆ Do not expose the battery to water.
- ◆ Do not short circuit the charging terminals on the vacuum cleaner bowl or the charging unit.
- ◆ Do not store in locations where the temperature may exceed 40°C.
- ◆ Charge only at ambient temperatures between 10°C and 40°C.
- ◆ Do not incinerate the battery.
- ◆ When disposing of batteries, follow the instructions given in the section "Protecting the environment".
- ◆ Have defective cords replaced immediately.
- ◆ Do not expose the charging base to water.
- ◆ Do not open the charging base.
- ◆ Do not probe the charger.

Electrical safety

Your charger has been designed for a specific voltage. Always check that the mains voltage corresponds to the voltage on the rating plate. Never attempt to replace the charger unit with a regular mains plug.



This appliance is double insulated; therefore no earth wire is required. Always check that the power supply corresponds to the voltage on the rating plate.



The charger is intended for indoor use only.



Read the instruction manual before use.



Charge only at ambient temperatures between 10°C and 40°C.

Features

This appliance includes some or all of the following features.

1. On/off power switch
2. Removable hose/handle
3. Locking ring
4. Hose
5. Filter cleaning wheel
6. Charging inlet
7. Transparent door
8. LED charging indicator
9. Door latch
10. 2-in-1 combi nozzle accessory
11. Accessory clip
12. Crevice tool

Assembly

Mounting accessories (fig. A & B)

The 2-in-1 combi nozzle (10) has a brush that can be folded forward for dusting and upholstery cleaning.

The crevice tool (12) allows for vacuuming in narrow and hard-to-reach places.

- ◆ To fit an accessory press the accessory clip (11) and slide the accessory onto the handle (2).
- ◆ To remove an accessory, press the accessory clip (11) and remove the accessory.

The handle (2) can be removed from the hose (4) allowing the accessories to be connected directly to the hose cuff (18) when required. To remove the handle:

- ◆ Unclip the handle (2) from the appliance.
- ◆ Rotate the locking ring (3) anti-clockwise to release the clips.
- ◆ Pull the hose (4) away from the handle (2).
- ◆ Fit the accessory directly to the hose cuff (18).

To refit the handle:

- ◆ Remove the accessory from the hose.
- ◆ Push the hose (4) into the handle (2). Rotate the locking ring (3) clockwise until it clicks into place.

Use

Before first use, the batteries must be charged for at least 16 hours.

- ◆ Connect the appliance to the charger for a minimum of 16 hours.
- ◆ Charge the batteries as described below.

You may need to charge/discharge the appliance a minimum of 5 times in order to achieve the best running time performance.

Charging the battery (fig. C)

Warning! Do not charge the battery at ambient temperatures below 10°C or above 40°C.

To charge the appliance:

- ◆ Make sure that the appliance is switched off. The battery will not be charged with the on/off power switch (1) in the on position.
- ◆ Insert the plug into the charging inlet (6) in the base.
- ◆ Plug in the charger and switch on at the mains.
- ◆ The charging indicator (8) will be lit.
- ◆ For the first charging, leave the appliance to charge for at least 16 hours.

Switching on and off

- ◆ To switch the appliance on, slide the on/off power switch (1) to the right to position 1.
- ◆ To switch the appliance off, slide the on/off power switch (1) to the left until it clicks into the off position.

Vacuuming

- ◆ When operating the appliance, make sure that the hose is not trapped, twisted or blocked.
- ◆ The handle (2) can be easily removed from the appliance allowing you to reach up to 1.5 m from the appliance.
- ◆ With the handle (2) removed, the appliance can be carried using the built-in handle.
- ◆ The handle (2) can also be removed from the hose (4) so that you can connect an accessory directly to the hose cuff (18) when required.

Hints for optimum use

- ◆ When vacuuming stairs, always start at the bottom and work your way up.

Optimising the suction force

In order to keep the suction force optimised, the filters must be cleared regularly during use.

- ◆ Turn the filter cleaning wheel (5) two turns clockwise to remove out any dust from the filters.
- ◆ The fine particulate filter must be cleaned regularly, see "Cleaning the fine particulate filter" section.

Cleaning and maintenance

Emptying the dust container (fig. D)

The dust container must be emptied regularly, preferably after every use.

- ◆ Release the door catch (9) and open the transparent door (7) 180° until it clicks in the open position.
- ◆ Remove the pre-filter (19).
- ◆ Empty the dust container.

- ◆ Clean the pre-filter (19) by lightly shaking over a dustbin.
- ◆ Refit the pre-filter (19).
- ◆ Close the transparent door (7) and make sure that it clicks into place.

Warning! Do not, under any circumstances, rinse out the dust container.

Warning! Do not immerse the appliance in water. A damp cloth and soapy water should be used to clean the exterior of the appliance. Always make sure that the appliance is completely dry before re-use or storing.

Cleaning the fine particulate filter (fig. E)

The fine particulate filter (20) prevents particles and larger objects from entering the motor housing.

The filter (20) is re-usable and should be cleaned regularly.

- ◆ Remove the pre-filter (19) from the appliance as described above.
- ◆ Remove the fine particulate filter (20) by pulling firmly.
- ◆ Tap the filter vigorously to remove loose dust from the filter.
- ◆ If necessary, wash the filter in warm, soapy water.
- ◆ Make sure that the filters are dry.
- ◆ Refit the fine particulate filter (20) on to the appliance.
- ◆ Refit the pre-filter (19) as described above.

Replacing the filters

The filters should be replaced every 6 to 9 months and whenever worn or damaged. Replacement filters are available from your Black & Decker dealer (cat. no. PD10):

- ◆ Remove the old filters as described above.
- ◆ Fit the new filters as described above.

Protecting the environment



Separate collection. This product must not be disposed of with normal household waste.

Should you find one day that your Black & Decker product needs replacement, or if it is of no further use to you, do not dispose of it with household waste. Make this product available for separate collection.



Separate collection of used products and packaging allows materials to be recycled and used again. Re-use of recycled materials helps prevent environmental pollution and reduces the demand for raw materials.

Local regulations may provide for separate collection of electrical products from the household, at municipal waste sites or by the retailer when you purchase a new product.

Black & Decker provides a facility for the collection and recycling of Black & Decker products once they have reached the end of their working life. To take advantage of this service please return your product to any authorised repair agent who will collect them on our behalf.

You can check the location of your nearest authorised repair agent by contacting your local Black & Decker office at the address indicated in this manual. Alternatively, a list of authorised Black & Decker repair agents and full details of our after-sales service and contacts are available on the Internet at: www.2helpU.com.

Batteries



Black & Decker batteries can be recharged many times. At the end of their useful life, discard batteries with due care for our environment.:

If you want to dispose of the product yourself, the batteries must be removed as described below and disposed of in accordance with local regulations.

- ◆ Discharge the battery by operating the appliance until the motor stops.
- ◆ Invert the appliance to get access to the screws that attach the base (fig. F).
- ◆ Remove the 8 screws (21).
- ◆ Remove the base.
- ◆ Disconnect the 3-pin connector.
- ◆ Place the battery in suitable packaging to ensure that the terminals cannot be short-circuited.
- ◆ NiCd batteries are recyclable. Take them to any authorised repair agent or a local recycling station.

EC declaration of conformity

PD1200B

Black & Decker declares that these products conform to:
2006/95/EC, EN 60335
Level of sound pressure, measured
according to EN 60704-1: = 72 dB(A)

The undersigned is responsible for compilation of the technical file and makes this declaration on behalf of
Black & Decker



Kevin Hewitt
Director of Consumer Engineering
Spennymoor, County Durham, DL16 6JG,
United Kingdom
05-03-2009

Please visit our website www.blackanddecker.co.uk to register your new Black & Decker product and to be kept up to date on new products and special offers. Further information on the Black & Decker brand and our range of products is available at www.blackanddecker.co.uk.

Guarantee

Black & Decker is confident of the quality of its products and offers an outstanding guarantee. This guarantee statement is in addition to and in no way prejudices your statutory rights. The guarantee is valid within the territories of the Member States of the European Union and the European Free Trade Area.

If a Black & Decker product becomes defective due to faulty materials, workmanship or lack of conformity, within 24 months from the date of purchase, Black & Decker guarantees to replace defective parts, repair products subjected to fair wear and tear or replace such products to make sure of the minimum inconvenience to the customer unless:

- ◆ The product has been used for trade, professional or hire purposes.
- ◆ The product has been subjected to misuse or neglect.
- ◆ The product has sustained damage through foreign objects, substances or accidents.
- ◆ Repairs have been attempted by persons other than authorised repair agents or Black & Decker service staff.

To claim on the guarantee, you will need to submit proof of purchase to the seller or an authorised repair agent. You can check the location of your nearest authorised repair agent by contacting your local Black & Decker office at the address indicated in this manual. Alternatively, a list of authorised Black & Decker repair agents and full details of our after-sales service and contacts are available on the Internet at:

www.2helpU.com

플렉시 12볼트 진공청소기

제품규격

	PD1200
전압	직류 12
무게	kg 1.8

충전기

입력전압	교류 230
대략 충전시간	시간 16
무게	kg 0.3

용도

Black & Decker Dustbuster Flexi 진공청소기는 가볍고 마른 먼지 등을 청소하도록 설계되었습니다. 본 제품은 가정용입니다.

안전 지침

경고! 배터리로 구동되는 제품을 사용할 때는 화재, 배터리 누액, 신체 부상 및 중대한 손상의 위험을 줄이기 위해 항상 다음과 같은 기본적인 안전 주의 사항에 따라 사용해야 합니다.

- ◆ 제품을 사용하기 전에 본 사용 설명서 전체 내용을 잘 읽고 숙지해주시시오.
- ◆ 본 사용 설명서에 제품의 용도가 설명되어 있습니다. 본 사용 설명서에서 권장하는 방식 이외의 다른 방식으로 본 제품을 조작하거나 액세서리 또는 부착물을 사용하는 경우 신체 부상의 위험이 있을 수 있습니다.
- ◆ 향후 참고할 수 있도록 본 사용 설명서를 잘 보관해두십시오

제품 사용시

- ◆ 본 제품을 물 근처에서 사용하지 마십시오.
- ◆ 본 제품으로 화재를 일으킬 수 있는 액체나 물질을 빨아들이지 마십시오
- ◆ 본 제품을 물 속에 담그지 마십시오.
- ◆ 충전기를 소켓에서 분리할 때 절대로 충전기 리드 선을 잡아당기지 마십시오. 충전기 리드 선이 열, 오일 및 날카로운 가장자리에 닿지 않도록 하십시오.
- ◆ 본 제품을 어린이나 심신 허약자 또는 초보자가 사용할 때는 안전을 책임질 수 있는 사람의 관리하에 있어야 합니다. 어린이가 본 제품을 가지고 놀지 못하도록 항상 주시해야 합니다.

제품 사용후

- ◆ 충전기 또는 충전 거치대를 청소하기 전에 충전기의 플러그를 뽑으십시오.
- ◆ 사용하지 않을 때에는 본 제품을 습기가 없는 건조한 장소에 보관해야 합니다.
- ◆ 어린이가 보관된 제품을 만지지 못하도록 해야 합니다.

검사 및 수리

- ◆ 사용 전, 제품에 손상되거나 결함 있는 부품이 있는지 점검하십시오. 부품 파손, 스위치 손상 등 정상적 사용에 영향을 미칠 수 있는 제품 이상이 있는지 점검하십시오.
- ◆ 손상되거나 결함 있는 부품이 있는 경우에는 제품을 사용하지 마십시오.
- ◆ 손상되거나 결함 있는 부품은 공인 수리 대리점에 의뢰하여 교체 또는 수리하십시오.
- ◆ 충전기 리드 선의 손상 여부를 주기적으로 점검하십시오. 리드 선이 손상되거나 결함이 발견되면 충전기를 교체하십시오.
- ◆ 본 사용 설명서에 명시된 내용 이외에는 어떤 부품도 제거하거나 교체하지 마십시오.

배터리 및 충전기 추가 안전 지침

배터리 및 충전기

- ◆ 절대로 배터리를 해체하거나 열려고 시도하지 마십시오.
- ◆ 배터리에 물이 닿지 않도록 하십시오.
- ◆ 진공청소기 또는 충전기의 충전 단자가 힙손되지 않도록 하십시오.
- ◆ 40°C 가 넘는 곳에 보관하지 마십시오.
- ◆ 주변 온도가 10°C~40°C 일때만 충전하십시오.
- ◆ 배터리를 소각하지 마십시오.
- ◆ 배터리를 폐기처분할 경우, "환경보호"부분의 지침에 따르십시오.
- ◆ 손상된 전원코드는 즉시 교체하십시오.
- ◆ 충전 거치대에 물이 닿지 않도록 하십시오.
- ◆ 충전 거치대를 열지 마십시오.
- ◆ 충전기를 분해하지 마십시오.

전기 안전

본 충전기는 특정 전압에서 작동하도록 설계되었습니다. 전원 전압이 명판에 기재된 전압과 일치하는지 항상 확인하십시오. 충전기를 절대로 일반 전원 플러그로 교체하지 마십시오



본 제품은 이중으로 절연되어 있어서 접지가 필요없습니다.



본 충전기는 실내용입니다.



사용전 사용메뉴얼을 자세하게 읽어주시기 바랍니다.



주변 온도가 10°C~40°C 일때만 충전하십시오.

기능설명

본 제품은 아래와 같은 기능들의 일부 또는 전체를 포함합니다.

1. On/Off 전원 스위치
2. 탈착 가능한 호스/핸들
3. 잠금 링
4. 호스
5. 필터 청소용 휠
6. 충전 포트
7. 투명 도어
8. LED 충전 지시등
9. 도어 잠금장치
10. 2-in-1 브러쉬 경용 노즐
11. 악세서리 클립
12. 틈새 노즐

제품 조립

악세서리 장착하기 (그림 A,B)

2-in-1 브러쉬 경용 노즐(10)에는 접이식 브러쉬가 장착되어 있으며 먼지 제거 나 직물류 청소에 사용합니다.

틈새 노즐(12)을 이용하여 좁은 공간이나 달기 어려운 곳을 청소할 수 있습니다.

“배터리 충전”부분을 참조하십시오.

- ◆ 악세서리를 장착하기 위해서는 액세서리 클립(11)을 누르고 액세서리를 핸들(2)에 밀어넣으십시오.
- ◆ 액세서리를 탈착하기 위해서는 액세서리 클립(11)을 누르고 액세서리를 분리하십시오.

핸들(2)은 호스(4)로부터 분리될 수 있으며 필요시 호스 커프(18)와 직접 연결할 수 있습니다.

핸들을 분리하려면 :

- ◆ 핸들(2) 을 본체에서 분리합니다.
- ◆ 잠금 링(3)을 시계바늘 반대방향으로 회전하여 클립을 분리합니다.
- ◆ 호스 (4) 를 핸들 (2) 로부터 제거합니다.
- ◆ 액세서리를 직접 호스 커프 (18) 에 설치합니다.

핸들을 재설치하려면 :

- ◆ 액세서리를 호스 커프로부터 제거합니다.
- ◆ 호스 (4) 를 핸들 (2) 에 밀어넣습니다. 잠금 링(3)이 클럭위치에 올 때까지 시계방향으로 돌립니다.

사용하기

처음 사용하기 전에 배터리를 16시간 이상 충전시켜야 합니다.

- ◆ 본체를 충전기에 16시간이상 연결합니다.
- ◆ 아래의 방법에 따라 배터리를 충전합니다.

최상의 사용시간 성능을 위해서는 5회이상 충전/방전시키는 것이 좋습니다.

배터리 충전하기 (그림 C)

경고! 주변온도가 10°C이하 또는 40°C이상 일 때 충전하지 마십시오.

청소기 충전 :

- ◆ 청소기 전원을 끈 상태에서 충전합니다. On/Off 전원 스위치(1)가 켜진 상태에서는 충전되지 않습니다.
- ◆ 플러그를 청소기 베이스의 충전 포트 (6)에 연결하십시오.
- ◆ 전원 플러그를 연결하고 전원 스위치를 켭니다.
- ◆ 충전 지시등(8)이 들어옵니다.
- ◆ 처음으로 배터리를 충전할 경우, 16시간이상 충전시켜야 합니다.

스위치 켜고 끄기

- ◆ 청소기 전원을 켤 경우, 전원 스위치(1)를 오른쪽 위치1로 하십시오.
- ◆ 청소기 전원을 끌 경우, 전원 스위치 (1)를 왼쪽의 Off 위치로 하십시오.

청소하기

- ◆ 청소기를 사용할 경우, 호스가 막히거나 또는 변형, 구부림이 없도록 하십시오.
- ◆ 핸들(2)을 분리하여 본체에서 1.5미터 정도까지 떨어진 곳까지 달을 수 있습니다.
- ◆ 핸들(2)이 분리된 후 내장된 핸들을 이용하여 청소기를 운반할 수 있습니다.
- ◆ 호스(4)로부터 핸들(2)을 제거할 수도 있으며 필요할 경우, 액세서리를 직접 호스 커프(18)에 연결하여 사용할 수 있습니다.

최적의 사용을 위한 힌트

- ◆ 계단을 청소할 경우, 계단 아래로부터 위 방향으로 청소합니다.

흡입력을 최적화하기

흡입력을 최적의 상태로 유지하기 위해서는 사용중 정기적으로 필터를 청소해야 합니다.

- ◆ 필터 청소용 휠(5)을 시계방향으로 2회 회전하여 필터의 먼지를 제거합니다.
- ◆ 작은 먼지용 필터도 정기적으로 청소해야 합니다. “작은 먼지용 필터”부분을 참조하십시오.

청소 및 유지보수 방법

먼지통 청소하기 (그림 D)

먼지통은 정기적으로 청소해야 합니다. 청소기를 사용할 때마다 청소할 것을 권장합니다.

- ◆ 도어 잠금장치(9)를 풀어서 투명 도어(7)가 열림 위치에 올 때까지 180° 여십시오.
- ◆ 1차 필터(19)를 분리하십시오.
- ◆ 먼지통을 비웁니다.
- ◆ 쓰레기통 위에 1차 필터를 살짝 흔들어 청소하십시오.
- ◆ 1차 필터(19)를 다시 설치합니다.
- ◆ 투명 도어(7)를 닫고 잠긴 것을 확인합니다.

경고! 어떠한 경우에도 먼지통을 물로 씻지 마십시오.

경고! 본체를 물에 넣지 마십시오. 본체 외부를 청소하기 위해서는 젖은 걸레와 비누물을 사용하십시오. 사용하거나 보관하기전에 본체가 충분히 건조되었는지 확인하십시오.

작은 먼지용 필터 청소방법 (그림 E)

작은 먼지용 필터(20)는 먼지 또는 큰 조각들이 모터 하우징에 들어가는 것을 막아줍니다.

필터(20)는 반복 사용 가능하며, 정기적으로 청소해야 합니다.

- ◆ 상기 방법에 따라 1차 필터 (19)를 본체에서 분리합니다.
- ◆ 작은 먼지용 필터(20)를 힘을 주어 당겨서 분리합니다.
- ◆ 필터를 두드려주면서 먼지를 제거합니다.
- ◆ 필요할 경우, 온수와 비누물로 필터를 청소합니다.
- ◆ 필터를 충분히 건조시킵니다.
- ◆ 작은 먼지용 필터(20)를 다시 청소기에 부착합니다.
- ◆ 상기 절차에 따라 1차 필터를 조립합니다.

필터 교체하기

6-9개월마다 또는 파손시 필터를 교체합니다. 교체용 필터는 지역 **Black & Decker** 대리점에서 구입할 수 있습니다. (품번 PD10)

- ◆ 상기 절차에 따라 기존 필터를 분리합니다.
- ◆ 상기 절차에 따라 새 필터를 조립합니다.

환경 보호



분리 수거. 본 제품을 일반 가정용 쓰레기로 처리하면 안됩니다.

Black & Decker 제품을 교체해야 할 경우, 또는 제품이 더 이상 필요되지 않을 경우, 일반 가정쓰레기와 구분하여 처리해야 합니다. 분리 수거하십시오.



사용하던 제품과 포장을 분리 수거하면 자원을 재활용 및 재사용할 수 있습니다. 재활용 자원을 이용하면 환경 오염이 방지되고 고철 자원에 대한 수요를 줄일 수 있습니다.

지역쓰레기처리장 또는 판매처에 현재 규정에 따라 전자제품 및 가정 쓰레기 구분에 관한 정보를 문의하십시오.

지역에 따라 가정용 가전제품을 분리 수거하는 규정이 마련되어 있거나 새로운 제품을 구입할 때 판매점에서 폐기 방법을 알려줄 수 있습니다.

Black & Decker는 사용이 끝난 **Black & Decker** 제품을 수집하여 재활용하기 위한 시설을 운영하고 있습니다. 이 서비스를 활용하려면 당사가 폐제품 수거를 위임한 공인 수리 대리점에 제품을 반환해 주십시오.

본 사용 설명서에서 기재된 연락처로 가까운 **Black & Decker** 영업소에 연락하면 가까운 공인 수리 대리점 위치를 확인할 수 있습니다. 또는 다음 웹 사이트를 방문하여 **Black & Decker** 공인 수리 대리점 목록과 애프터 서비스 및 연락처에 대한 등 자세한 정보를 찾아볼 수 있습니다.

www.2helpU.com.

배터리



Black & Decker 배터리는 반복적으로 충전하여 사용할 수 있습니다. 사용수명이 다 되었을 때는, 환경보호를 위한 방법으로 폐기처리하십시오.

제품을 직접 폐기하실 경우, 아래의 절차에 따라 배터리를 분리하시고 지역 법규에 따라 처리해야 합니다.

- ◆ 모더가 멈출 때까지 제품을 작동시켜 배터리를 방전시킵니다.
- ◆ 청소기 본체 하부(그림 F)에 설치된 나사못를 확인하십시오.
- ◆ 8개의 나사못을 제거하십시오. (21).
- ◆ 청소기 베이스를 제거하십시오.
- ◆ 3핀 커넥터를 차단하십시오.
- ◆ 배터리를 적절한 포장에 넣어 전극이 함선되지 않도록 하십시오.
- ◆ 니켈-수소 배터리는 재활용할 수 있습니다. 지정된 판매처 또는 현지 회수업체에 반납하십시오.

EC관련 합격증명

PD1200B

Black & Decker는 본 제품이 이하 규정 요구사항을 만족함을 증명합니다:

2006/95/EC, EN 60335

사운드 등급, EN 60704-1에

따른 측정결과값: = 72 dB(A)

이하 서명은 기술규격서 작성에 대한 확인으로,
Black & Decker의 이에 따른 성명을 의미합니다.



Kevin Hewitt

소비자 총괄담당

Spennymoor, County Durham, DL16 6JG,

United Kingdom

05-03-2009

품질 증명서

Black & Decker는 당사 제품에 대한 품질을 보증합니다.

아울러 고객님의 해당 법적 규정에 따른 권리를 존중합니다. 품질보증은 유럽연맹 및 유럽자유무역구내에 효력을 보장합니다.

Black & Decker제품의 자재, 공정 등으로 제품 하자 또는 불량 발생될 경우, 제품 구입 당일로부터 24개월내에 무상으로 하자가 있는 부속품을 교체해 드립니다. 정상적으로 마손된 제품을 교환해 드리며 소비자들의 불편사항을 최소화해 드립니다. 단, 이하 경우는 품질보증에 적용되지 않습니다:

- ◆ 본 제품이 무역, 또는 전문 사용목적 및 임대용으로 사용할 경우.
- ◆ 본 제품이 잘못 사용될 경우.
- ◆ 본 제품이 외부충격 또는 외부손상으로 파손될 경우.
- ◆ 지정된 유지보수 업체 또는 Black & Decker 전문담당직원 외 본 제품을 분해 또는 수리할 경우.

제품을구입하신후 품질보증 서비스를 받기 위하여 판매처 또는 지정 수리업체로부터 해당 영수증을 요청하십시오. 매뉴얼에 제시된 주소에 근거하여 현지 Black & Decker사무소에 의뢰하시거나 또는 인근지역의 지정 수리업체에 의뢰하시면 됩니다. 그외에, www.2helpU.com 에 방문하시고 웹사이트의Black & Decker지정 수리업체 및 당사 A/S담당직원 연락처를 찾아보실수 있습니다.

www.2helpU.com

당사 웹사이트 www.blackanddecker.co.uk 를 방문하시고 고객님의께서 구입하신 Black & Decker 제품을 등록하시고 제품 갱신 및 특별할인을 받으실수 있습니다. Black & Decker 브랜드 및 제품에 관한 세부정보는 www.blackanddecker.co.uk 를 방문하시기 바랍니다.