




APR1



APR1 AIR POP RIVET GUN

INDEX	PART NO.	DESCRIPTION	QTY.
1	APR1-01	3/32" NOSEPIECE	1
2	APR1-02	1/8" NOSEPIECE	1
3	APR1-03	5/32" NOSEPIECE	1
4	APR1-04	3/16" NOSEPIECE	1
5A	APR1-05A	JAW CASE ASSEMBLY (WITH JAWS)	1
8	APR1-08	JAW PUSHER	1
9	APR1-09	CASE WASHER RING	1
10	APR1-10	JAW PUSHER SPRING	1
11	APR1-11	FRAME HEAD	1
12	APR1-12	CASE LOCK NUT	1
13	APR1-13	PLASTIC BACKUP RING	1
14	APR1-14	BACKUP "O" RING (SET OF 2)	1
15	APR1-15	FRAME	1
16	APR1-16	OIL PISTON	1
17	APR1-17	PISTON "O" RING	1
18	APR1-18	BACKUP RING	1
19	APR1-19	RETURN SPRING	1
20	APR1-20	HANGING CLIP	1
21	APR1-21	FRAME CAP	1
22	APR1-22	SAFETY CAP NUT	1
23	APR1-21	SAFETY CAP	1
24	APR1-24	SETTING SCREW	1
25	APR1-25	PISTON "O" RING SET OF 2	1
26	APR1-26	BACKUP RING	1
27	APR1-27	FRAME LOCK NUT	1

INDEX	PART NO.	DESCRIPTION	QTY.
28	APR1-28	RUBBER CUSHION	1
29	APR1-29	AIR CYLINDER	1
30	APR1-30	AIR PISTON ASSEMBLY	1
31	APR1-31	AIR PISTON "O" RING	1
32	APR1-32	CYLINDER "O" RING	1
33	APR1-33	CYLINDER CAP	1
34	APR1-35	SPANNER GAUGE	1
35	APR1-36	SPANNER	1
36	APR1-37	TRIGGER PIN	1
37	APR1-38	CONNECTOR PIN	1
38	APR1-39	TRIGGER ROD	1
39	APR1-40	TRIGGER	1
40	APR1-41	CONNECTOR PIN	1
41	APR1-42	TRIGGER LEVER	1
42	APR1-43	LEVER PIN	1
43	APR1-44	VALVE PUSHER	1
55	APR1-55	BRASS BUSHING	1
56	APR1-56	O-RING	1
57	APR1-57	BALL	1
58	APR1-58	SPRING	1
59	APR1-59	O-RING	1
60	APR1-60	CAP	1
***	APR1-45	VALVE PUSHER O-RING	1
***	APR1-46	VALVE COLLAR	1
***	APR1-51	NIPPLE	1
***	APR1-52	JOINT NUT	1
***	APR1-54	SPRING	1

*** NOT SHOWN