






STANLEY



STEL670

English
繁體中文

3
6



STEL670 1500W Heat Gun

Technical data

SPECIFICATION		STEL670
POWER	W	1500
HEAT SETTING		Variable
SWITCH CONTROL		2 Stage (I/ II)
TEMPERATURE	°C	50-450/ 90-600
AIR FLOW	l/mim	300/ 500
CABLE LENGTH	m	2

Intended Use

Your Stanley heat gun has been designed for various heating applications (eg. Paint stripping)

General safety rules

Warning! Read all instructions. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury. The term "power tool" in all of the warnings listed below refers to your mains operated (corded) power tool or battery operated (cordless) power tool.

SAVE THESE INSTRUCTIONS.

1. Work area

- Keep work area clean and well lit.** Cluttered and dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

2. Electrical safety

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep**

cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.

- When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.

3. Personal safety

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
- Use safety equipment. Always wear eye protection.** Safety equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- Avoid accidental starting. Ensure the switch is in the off position before plugging in.** Carrying power tools with your finger on the switch or plugging in power tools that have the switch on invites accidents.
- Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
- Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts.** Loose clothes, jewellery or long hair can be caught in moving parts.
- If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of these devices can reduce dust related hazards.
- Use clamps or another practical way to secure and support the workpiece to a stable platform.** Holding the work by hand or against your body leaves it unstable and may lead to loss of control. Before drilling into walls, floors or ceilings check for the location of wiring and pipes. Avoid touching the tip of a drill bit just after drilling, as it may be hot.
- Power tool use and care**
 - Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
 - Do not use the power tool if the switch does not**

turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.

- c. **Disconnect the plug from the power source before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d. **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
- e. **Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tools operation. If damaged, have the power tool repaired before use.** Many accidents are caused by poorly maintained power tools.
- f. **Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- g. **Use the power tool, accessories and tool bits etc., in accordance with these instructions and in the manner intended for the particular type of power tool, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could result in a hazardous situation.

5. Service

- a. **Have your power tool serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the power tool is maintained.

Additional Safety Instructions for Heat Guns

- **Always switch off before putting tool down.**
- **Extreme care should be taken when stripping paint,** the peelings, residue and vapors of paint may contain lead, which is poisonous. Once deposited on surfaces, hand to mouth contact can result in the ingestion of lead. Exposures to even low levels of lead can caused irreversible brain and nervous system damage; young and unborn children are particularly vulnerable. Do not smoke, eat or drink in a work area that could or may be contaminated by lead. **Lead based paints should only be removed by a professional and should not be removed using a heat gun.**
- **When removing paints you should ensure that your work area is enclosed.** It is advisable to wear a dust mask.

- **Do not burn the paint.** Keep the nozzle at least 25mm (1") from the surface as this keeps the temperature below the required 450°C. If you are scraping from a vertical position then you should scrape downwards to prevent the paint from falling back into the heat gun and burning. Dispose of all paint debris safely and ensure that the work area is thoroughly cleaned after completing the job.
- **Do not use in a damp atmosphere or where flammable gases may be present** or use near combustible materials. Spaces behind boards, ceilings and floors and wall cavities in timber frame constructed houses can contain flammable materials. Check before using the heat gun.
- **Allow the tool to cool fully before storing.**
- **Ensure adequate ventilation** when using heat guns as toxic fumes may be produced.
- **Do not use as a hairdryer!** The air temperature is far higher than a hairdryer.
- **Do not obstruct** either the air intake or nozzle outlet as this may cause excessive heat build up resulting in damage to the tool.
- **Do not direct the hot air blast at other people.**
- **Do not touch the metal nozzle** as it becomes very hot during use and remains hot for up to 30 minutes after use. Do not look down the nozzle while the unit is working because of the high temperatures being produced.
- **Do not allow paint to adhere** to the nozzle or scraper as it could ignite after a time.
- **Do not operate your heat gun** whilst it is hanging by the hanging hook.
- **A fire may arise if the appliance is not used with care.**
- **Do not place the nozzle against anything while using or immediately after use.**
- **Do not poke anything down the nozzle as it could give you an electric shock.**

Features (fig. A)

1. Switch
2. Heat control knob
3. Ventilation slots
4. Nozzle

Handling Your Heat Gun

Do not place your hand over the ventilation slots (3) or block these vents in any way. This restricts the airflow through the element and causes over heating.

Setting the temperature (fig. B)

- To increase the temperature setting, turn the heat control knob (2) anti-clockwise.
- To reduce the temperature setting, turn the heat control knob clockwise.

Operating Your Heat Gun (fig. C)

- To switch your heat gun on at the low temperature setting, press the switch (1) to depress to position "I".
- To switch the tool on at the high temperature setting, set the switch (1) to position "II".
- To switch the tool off, set the on/off switch (1) to position "0".

Note: Allow the element to heat up for a few seconds before use. Initially, some smoke may emit from your heat gun. This is normal and will soon cease.

Cooling Down

In use, the nozzle (4) of your heat gun becomes extremely hot. Great care is necessary when cooling your heat gun after use.

Hands Free Use (fig. D)

This tool can also be used in stationary mode.

- Place the tool onto a firm and stable surface as shown.
- Always point your heat gun away from you.
- Secure the cable to prevent pulling your heat gun off the stand.

Do not touch the nozzle (4) and ensure that nothing is dropped into the nozzle. Carefully switch off your heat gun

⚠ and then allow it to cool

Paint Stripping

Your heat gun is designed to soften paint and lacquer enabling it to be removed using a good quality hand scraper.

Proceed as follows: Direct the hot air onto the area to be removed. When the paint softens, scrape firmly. Experiment to establish the length of time necessary to apply the heat to obtain optimum results. Scrape the softened paint immediately or it will harden again.

Your heat gun is not suitable for stripping metal-framed windows. This is because the heat from the heat gun is conducted through the metal and can crack the glass. Scrape with the grain of the wood wherever possible. Do not linger on one spot for too long as the surface may char or ignite.

Accessories

The performance of your tool depends on the accessory used. Stanley and Piranha accessories are engineered to high quality standards and designed to enhance the performance of

your tool. By using these accessories you will get the very best from your tool.

Maintenance

Your tool has been designed to operate over a long period of time with a minimum of maintenance. Continuous satisfactory operation depends upon proper tool care and regular cleaning.

Warning! Before performing any maintenance, switch off and unplug the tool.

- Regularly clean the ventilation slots in your tool using a soft brush or dry cloth.
- Regularly clean the motor housing using a damp cloth. Do not use any abrasive or solvent-based cleaner.

Protecting the environment



Separate collection. This product must not be disposed of with normal household waste.

Should you find one day that your Stanley product needs replacement, or if it is of no further use to you, do not dispose of it with household waste. Make this product available for separate collection.



Separate collection of used products and packaging allows materials to be recycled and used again. Re-use of recycled materials helps prevent environmental pollution and reduces the demand for raw materials.

Local regulations may provide for separate collection of electrical products from the household, at municipal waste sites or by the retailer when you purchase a new product.

STEL670**1500 瓦熱風槍****技術資料**

規格		STEL670
功率	瓦特	1500
加熱設定		可調
開關控制		2 檔 (I / II)
溫度	°C	50-450/ 90-600
空氣流量	l/mim	300/ 500
電纜長度	m	2

設計用途

您的 Stanley 熱風槍設計用於各種加熱用途（例如：除漆）。

一般安全規定

警告！請閱讀所有指示。不遵循下列的任何指示可能會導致觸電、火災及/或嚴重傷害。下列所有警告中的名詞「電動工具」是指電源驅動（插電）電動工具，或者電池驅動（充電）電動工具。

妥善保存這些安全指示。**1. 工作場地**

- 保持工作場地清潔和明亮。混亂和黑暗的場地會引發事故。
- 不要在易爆環境，如有易燃液體、氣體或塵埃的環境中操作電動工具。電動工具產生的火花會點燃塵埃或氣體。
- 請等待兒童和旁觀者離開之後才操縱電動工具。分心會導致您疏於控制。

2. 電力安全

- 電動工具插頭必須與插座相符。請勿以任何方式改裝插頭。需接地的電動工具不能使用任何配接器插頭。未經改裝的插頭和相符的插座可以減少觸電危險。
- 避免人體接觸接地表面，如管道、散熱片、爐灶和冰箱。若您的身體接地，會增加觸電危險。
- 不得將電動工具暴露在雨中或潮濕環境中。水進入電動工具會增加觸電危險。
- 請勿濫用電線。請勿使用電線來搬運、拉動電動工具或拔出插頭。讓電線遠離熱、油、銳邊或活動部件。受損或纏繞的電線會增加觸電危險。
- 若要在戶外使用電動工具，請使用適合戶外使用的延長電線。使用適合戶外使用的電線可減少觸電危險。

3. 人身安全

- 保持警覺；在操作電動工具時，請留意所執行的操作並按照一般的流程執行。請勿在疲倦，或受到藥物、酒精或治療的影響下操作電動工具。操作電動工具期間注意力分散會導致嚴重人身傷害。
- 使用安全裝置。始終佩戴護目裝備。安全裝置，例如在適當條件下使用的防塵面具、防滑安全鞋、安全帽或聽力保護等裝置可減少人身傷害。
- 避免意外啟動。接通電源前請確定開關處於關閉位置。搬運電動工具時若將手指放在開關上，或是在接通電動工具電源時插入插頭都會引發危險。
- 接通電動工具之前，請卸下所有的調整鑰匙或扳手。遺留在電動工具旋轉部件上的扳手或鑰匙會導致人身傷害。
- 不要過度伸張雙手。時刻注意腳下和身體的平衡。如此即可在發生意外的情況下更好地控制電動工具。
- 適當穿著。不要穿寬鬆衣服或佩戴飾品。讓您的頭髮、衣服和手套遠離活動部件。寬鬆衣服、佩飾或長髮可能會捲入活動部件。
- 若配備用於連接排屑裝置、集塵設備的裝置，請確定正確連接和使用這些裝置。使用這些裝置可減少與塵埃有關的危險。
- 使用夾具或採取其他可行的方法，將工件固定、支撐到穩定的平台上。手持工件或用身體抵住工件會使工件不穩定並可能導致失控。
在牆體、地板和天花板上鑽孔之前，請檢查電線和管道位置。
不要在鑽孔後立刻碰觸可能還帶熱的鑽頭尖端。

4. 電動工具的使用與注意事項

- 不要超負荷使用電動工具。根據您的用途使用適當的電動工具。使用適當的電動工具在其設計可負荷的應用內，會讓您更有效、更安全地執行工作。
- 若開關不能開啟或關閉電源，請勿使用該電動工具。不能用開關來控制的電動工具將存在危險，因此必須進行修理。
- 在更換配件、儲存工具或執行任何調整之前，必須從電源上拔下插頭。這類防護性安全措施可降低電動工具意外啟動的風險。
- 將閒置的電動工具儲存在兒童無法接觸的地方，並且不要讓不熟悉電動工具或對這些使用指示不瞭解的人員操作電動工具。電動工具在未經培訓的使用者手中會發生危險。

- e. 維護電動工具。檢查活動部件是否對準或卡住、破損情況以及是否存在影響電動工具運行的其他情況。若有損毀，必須在使用之前修理電動工具。許多事故都是由於電動工具欠缺維護所導致。
 - f. 保持刀具鋒利和清潔。妥善維護、切削鋒利的刀具不會輕易卡住並可更輕鬆控制。
 - g. 遵循使用指示和特定工具類型的設計用途，以及工作條件和所要執行的工作使用電動工具、配件和工具鑽頭等。不按照設計目的使用電動工具會導致危險。
5. 檢修
- a. 本電動工具必須由合格的維修人員並只採用相同的替換零件來執行檢修。這樣將確保電動工具的安全。

熱風槍之附加安全指示

- 放下工具之前，請務必關閉工具電源。
- 除漆作業時要加倍小心。剝落的油漆、油漆殘渣及煙霧可能含鉛，而鉛是一種有毒物質。一旦積存在表面，手至口的接觸可能令您吞下鉛。即使吸收到很少的鉛都會引致不能治愈的腦及神經系統的損害，小孩和胎兒則更容易受傷害。請勿在可能受鉛污染的工作場地吸煙或飲食。請勿使用熱風槍去除含鉛的油漆，應由專業人士進行除漆作業。
- 除漆時請確保工作場地是封閉的；並請佩戴防護面具。
- 請勿焚燒油漆。出風口與除漆表面應保持 25 mm (1") 的距離，以保持溫度在所需的 450° C 以下。若您以垂直線的方向刮起油漆，則應向下刮以免油漆掉入熱風槍內并焚燒。工程完畢後應將工作場地徹底清潔並安全地處置所有漆屑。
- 請勿在潮濕或可能存有易燃氣體或易燃材料附近的環境下使用熱風槍。以木材作框架的間牆板後、天花板、地板及牆洞都可能存有易燃材料。使用熱風槍之前，請選檢查是否存在有易燃材料。
- 熱風槍要完全冷卻後才能儲存。
- 確保環境中有大量新鮮空氣流通，因為使用熱風槍時可能會產生有毒氣體。
- 請勿將熱風槍作為吹風機使用！熱風槍的溫度遠比吹風機溫度要高。
- 請勿堵塞熱風槍之進風口或出風口，否則會導致熱風槍過熱而造成工具損壞。
- 請勿將熱風噴向任何人。
- 請勿觸摸熱風槍的金屬出風口。熱風槍在使用時非常高溫，且在關閉工具電源後的三十分鐘內其

溫度仍會維持。請勿在熱風槍啟動時正視其出風口，因為高溫會產生。

- 請勿讓油漆附著在出風口或刮刀上，否則一段時間後油漆會燃燒。
- 請勿在熱風槍掛在掛鉤上時啟動熱風槍。
- 若沒有小心使用熱風槍，會有導致火災的危險。
- 請勿在使用時或用完後馬上將熱風槍靠攏任何對象。
- 請勿讓任何物件掉入出風口以免受電擊。

功能部件 (圖 A)

1. 開關
2. 熱控旋鈕
3. 通風槽
4. 出風口

正確使用熱風槍

請勿將手放在通風槽 (3) 上或以任何形式堵塞通風槽。這會阻礙空氣流通而導致熱風槍過熱。

設定溫度 (圖 B)

- 要使溫度升高，逆時針旋轉熱控旋鈕 (2) 即可。
- 要使溫度降低，順時針旋轉熱控旋鈕即可。

操作熱風槍 (圖 C)

- 要將熱風槍溫度切換至低溫，請按壓開關 (1) 至「I」的位置。
- 要將熱風槍溫度切換至高溫，請按壓開關 (1) 至「II」的位置。
- 若要關閉工具電源，請將 on/off 開關 (1) 撥到「0」的位置。

注：使用前請先把熱風槍預熱數秒。啟動初期，熱風槍會有少量煙冒出，這是正常現象，並且會很快停止。

冷卻

熱風槍的出風口 (4) 的溫度在使用時會變得非常高溫。使用後必須冷卻熱風槍。

免提操作 (圖 D)

本工具的設計可使它立在平面上使用。

- 將工具置於穩固的作業面上，如圖所示。
- 請勿將熱風槍指向自己。
- 固定電纜以免它將熱風槍拉倒。



請勿觸摸出風口 (4)，並確保沒有任何物件掉入出風口。小心關閉熱風槍電源並讓其冷卻。

除漆

本熱風槍設計用於軟化油漆和亮漆，使您能夠使用優質刮刀將油漆除掉。請按以下方式進行：將熱風吹向要除漆的表面。當油漆軟化後，使力把油漆刮除。要獲得最佳除漆效果，需進行數次試驗測試需時多久才可把油漆軟化。一旦油漆軟化後，應立即將油漆刮掉，否則它很快便會變硬。

本熱風槍不適用於在金屬窗框上除漆。這是因為熱風槍的熱力會透過金屬窗框並令玻璃破裂。盡可能沿著木材的紋理刮除油漆。請勿讓熱風噴向同一點太久，否則工件表面會燒焦或燃燒。

配件

電動工具的效能取決於所使用的配件。Stanley and Piranha 配件依據高品質標準進行規劃，並設計用於增強電動工具的效能。透過使用這些配件，您可以獲得工具的最佳效能。

維護

本電動工具採用卓越的設計，能夠長時間使用，並且只需最少的維護。若要持續獲得滿意的操作效果，需進行正確的工具維護和定期的清潔。

警告！ 在工具上執行任何維護工作之前，請關閉電源並拔下工具的插頭。

- 定期使用軟刷或乾布清潔工具內的通風槽。
- 定期使用濕布清潔電動機外殼。請勿使用任何研磨型或溶劑型清潔劑。

保護環境



個別收集。本產品必須與一般家庭廢物分開處置。

物一起處置。務必將本產品送往個別收集處。



個別收集用過的產品和包裝允許材料再循環利用。重新使用循環利用的材料有助於防止環境污染，並減少原始材料的需求。

當地法規可能要求由市政廢物回收點，或由向您出售新產品的經銷商來提供從家庭中個別收集電器產品的服務。

進口商：永安實業股份有限公司

電話：02-29994633

地址：新北市三重區新北大道二段137號